

## How to use the program guide to find shows

The on-screen program guide displays up to two weeks of TV programming. To reach the Guide, select the Guide button on the remote or go to the Home screen and choose Guide.


While you're watching TV, press UP on your remote control to see the mini guide: a smaller version of the guide that shows you what's coming up on the channel you're watching; press UP/DOWN to view other channels.

Icons in the guide help you navigate to the shows you want. New shows are marked with a NEW icon. When you highlight a cell in the guide, shows that are currently recording have a red circle icon next to the title, while shows that are scheduled to record are marked with a check mark (for individual shows) or double check mark (for OnePass recordings).

You can choose to view all channels in your lineup or favorite channels only. Highlight a channel name/number (not a show) and press OK. Then use the Channels option to choose a channel list:

- **All:** Displays all channels in your lineup.
- **Favorites:** Displays your favorite channels only. Choose your favorite channels by going to the program guide and selecting a channel name/number (not a show). Press OK, then select Add to Favorite Channels.

To move around in the guide:

- Press RIGHT and LEFT to move the displayed time ahead two hours (one page), or press REWIND to move it backward.
- Press OK on a show in progress, and the channel changes to that show.
- Press OK on an upcoming show, and you'll see recording, OnePass, and bookmarking options. Choose an option or press Back to go back to the guide. Note that some channels and individual shows may not be available to record.
- Press OK on a past show, or a show in progress with a Restart & Catch Up icon , and you'll see Restart and Catch Up options.